

# CROWNLINE VALVE & HOSE CABINET DOOR STYLES



F - Full glass with pull



D - Horizontal duo panel with pull



V - Vertical duo panel with pull



S21- Solid with pull



B10 - Solid with pull, view window & Saf-T-Lok™



A - Centered Horizontal Panel with Saf-T-Lok™



Dual cabinet with shelf - 8000 Series



G - Full glass with pull & Saf-T-Lok™



E - Horizontal duo panel with pull and Saf-T-Lok



W - Vertical duo panel w/ pull & Saf-T-Lok



L22 - Solid with pull & Saf-T-Lok



L24 Solid with cylinder key lock & no pull

**Note: If lock option is selected, lock is centered vertically on door, and the center of the handle will be 3-5/8" above the lock in most cases.**

**Please allow for this when positioning cabinet for installation. See page 2 for details.**



SAF-T-LOK™ IS A TRADEMARK OF ACTIVAR  
 DOWNLOAD CURRENT SUBMITTAL BEFORE ORDERING

**CABINET DOOR STYLES - CROWNLINE VALVE & HOSE CABINETS**  
**See page 3 for details of handle height and ADA-mounting**

© 2019 Activar Construction Products Group, Inc.

**HEADQUARTERS:** 9702 NEWTON AV S, BLOOMINGTON, MN 55431 **PH:** 800-554-6077 **FAX:** 952-835-2218 **EMAIL:** SALES@ACTIVARCPG.COM WWW.ACTIVARCPG.COM 10/17/2019  
**MANUFACTURING:** BLOOMINGTON MN & COMMERCE CA **WAREHOUSES:** LANCASTER - PA, DALLAS - TX, ATLANTA - GA, CHICAGO IL, SEATTLE WA, FARGO ND, OMAHA NE, FORT MYERS FL

## CABINET GLAZING — CROWNLINE



10 CLEAR ACRYLIC  
17 CLEAR TEMPERED  
18 LAMINATED SAFETY GLASS



15 BRONZE ACRYLIC  
COMPLETELY  
OBSCURES CONTENTS




16 GRAY ACRYLIC  
SHADES VIEW OF  
CONTENTS



13 CLEAR WIRE GLASS  
WITH SAFETY FILM


## ADA MOUNTING HEIGHT

Door with Standard Pull Centered & No Lock - F, S, V, D,  
L24 or Any Door with Flush Pull




**Calculate Bottom Edge of Wall Opening  
to Have Door Pull Centered at 48" AFF:**

48" minus (Wall Opening Height Divided by 2).  
Example for 1017F10:  $48" - (25" \div 2) = 35.5" \text{ AFF}$



Example for 24" High Non FX Cabinet

Door with Standard Pull & Lock -  
E, G, W, A, B10, L22



Lock is Centered  
on Door

Pull is Centered  
3-5/8" Above Lock

**Calculate Bottom Edge of Wall Opening  
to Have Door Pull Centered at ~ 48" AFF:**  
44" minus (Wall Opening Height Divided by 2).  
Example for 1017G10:  $44" - (25" \div 2) = 31.5" \text{ AFF}$

